



SYSTEM PROGRAMMING GUIDE (728ULT)

Software Version 4.0

INSTALLER CODE (Default: 282828)

Full access to programming, except user access codes (PINs). No access to arming/disarming. Use only numeric keys from [0] to [9].

ZONE RECOGNITION

Table 1: Zone Recognition

Device connected to which input?	No ATZ	With ATZ
Control Panel		
Input 1 =	Zone 1	Zones 1 & 2
Input 2 =	Zone 2	Zones 3 & 4
Input 3 =	Zone 3	Zones 5 & 6
Input 4 =	Zone 4	Zones 7 & 8
Keypad		
Zone 1 =	Zone 5	Zone 9
Zone 2 =	Zone 6	Zone 10

STREAMLINED SECTION PROGRAMMING

This is an alternate method to Hexa Programming (see page 2). Addresses 000 to 043 and 300 to 527 are grouped into 67 sections where each section contains four addresses (i.e. section 00 = addresses 000 to 003). Using this method allows you to program 8 digits (4 addresses) without having to exit and reenter addresses.



Note, the keypad will not display the current data in the Streamlined Section Programming method.

Table 2: Streamlined Section Programming Method

1) Press [ENTER] + [INSTALLER CODE] (default: 282828) + [7]
2) The [ENTER] and [2ND] keys will flash to indicate you are in programming mode
3) Enter 2-digit [SECTION] (00 to 67)
4) The [ENTER] key will remain on while the [2ND] key will be off
5) Enter 8-digit [DATA] to program the section
6) The keypad will "beep" to indicate that the section has been programmed, data is saved and the software has advanced to the next section
7) Return to step 4 or press [CLEAR] to exit programming mode

KEYPAD TROUBLE DISPLAY

Press the [TBL]/[TRBL] key to view the trouble. Any illuminated keys represent a specific trouble as indicate in Table 3 below. Press the [CLEAR] button to exit the trouble display.

Table 3: Trouble Display

[1] - No Battery or Low Voltage	[7] - Communicator Report Failure
[2] - Power Failure	[8] - Timer Loss* (to clear, see [MEM] key in Table 11 on page 11)
[4] - Bell Output Disconnected	[9] - Tamper or Zone Wiring Failure
[5] - Exceeded Maximum Bell Current	[10] - Telephone Line Monitoring Failure
[6] - Exceeded Maximum Auxiliary Current	[11] - Fire Loop Trouble


HEXA PROGRAMMING

This is an alternate method to the Streamlined Section Programming (see page 1). Addresses **000** to **043** and **300** to **527** can be programmed using the Hexa Programming method. In this mode, you can enter any hexadecimal digit from 0 - F where keys **[1]** to **[9]** represent digits 1 to 9 respectively; the other keys represent hexadecimal digits A to F as shown in Figure 1 below.

Table 4: Hexa Programming Method

- 1) Press **[ENTER]** + **[INSTALLER CODE]** (default: 282828)
- 2) The **[ENTER]** key will flash indicating you are in programming mode
- 3) Enter the desired 3-digit **[ADDRESS]**
- 4) The keypad will display the 2-digit data currently saved at this address as described in Figure 1 below
- 5) Enter 2-digit **[DATA]** and do not press **[ENTER]**, the software automatically saves the data
- 6) Return to step 2 or press **[CLEAR]** to exit programming mode

Figure 1: Hexa Digit Data Entry and Data Display for LED Keypads



INSTALLER / PANEL ANSWER OPTIONS

Streamline Section	Data	Description	Address
00	___ / ___	Installer code (1st, 2nd digit)	000
	___ / ___	Installer code (3rd, 4th digit)	001
	___ / ___	Installer code (5th, 6th digit)	002
	___ / ___	Panel answer options	003

↳ Number of rings (Max. 15)

Answering Machine Override

[2ND] or [1] = disabled	[5] = 40 seconds
[2] = 16 seconds	[6] = 48 seconds
[3] = 24 seconds	[7] = 56 seconds
[4] = 32 seconds	[8] to [F] = 60 seconds

↑ First digit disables "Answering Machine Override" (key **[2ND]** or key **[1]**), or determines period of time between first and second call. Second digit determines number of rings required before panel will answer. If **[2ND][2ND]** is entered, panel will not answer (default value is **[2ND] [8]**).

Streamline Section	Data	Description	Address
01	___ / ___	Panel Identifier (1st, 2nd digit)	004
	___ / ___	Panel Identifier (3rd, 4th digit)	005
	___ / ___	PC Password (1st, 2nd digit)	006
	___ / ___	PC Password (3rd, 4th digit)	007

} Identifies the control panel to the PC.

} Identifies the PC to the control panel.

TELEPHONE AND ACCOUNT NUMBERS

If only one central station phone number is used, program the same number for telephone number 1 and 2. If only one account number is required, the same number must be entered for both account "A" and "B".

[0] to [9] = numeric value [BYP] = switch from pulse to tone while dialing
[11] = * [MEM] = pause 4 seconds
[12] = # [TRBL] = end of number

Computer Telephone Number (View at addresses 008 to 015)

Streamline Section

02

1 2 3 4 5 6 7 8

Streamline Section

03

9 10 11 12 13 14 15 16

Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.

Central Station Telephone Number 1 (View at addresses 016 to 023)

Streamline Section

04

1 2 3 4 5 6 7 8

Streamline Section

05

9 10 11 12 13 14 15 16

Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.

Central Station Telephone Number 2 (View at addresses 024 to 031)

Streamline Section

06

1 2 3 4 5 6 7 8

Streamline Section

07

9 10 11 12 13 14 15 16

Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.

Account "A" and "B" (View at addresses 032 to 035)

Streamline Section

08

1 2 3 4 5 6 7 8
A B

For 3 digit account numbers, enter "skip" ([2ND]) as first digit.

Streamline Section	Data	Description	Address	Pager Delay Table (1st digit)	
09	[2ND] / [2ND]	Future Use	036	[2ND] or [1] = 8 secs.	[9] = 72 secs.
	___ / ___	1st digit: Pager Delay (see table at right)	037 →	[2] = 16 secs.	[A] = 80 secs.
	___ / ___	2nd digit: Time correction (see table at right)		[3] = 24 secs.	[B] = 88 secs.
10	___ / ___	1st digit: Communicator Format 1	038	[4] = 32 secs.	[C] = 96 secs.
	___ / [2ND]	2nd digit: Communicator Format 2	039	[5] = 40 secs.	[D] = 104 secs.
	___ / [2ND]	1st digit: PGM1 type		[6] = 48 secs.	[E] = 112 secs.
				Time Correction Table (2nd digit)	
				[2ND] = No adjustment	[8] = Minus 4 secs.
				[1] = Plus 4 secs.	[9] = Minus 8 secs.
				[2] = Plus 8 secs.	[10] = Minus 12 secs.
				[3] = Plus 12 secs.	[11] = Minus 16 secs.
				[4] = Plus 16 secs.	[12] = Minus 20 secs.
				[5] = Plus 20 secs.	[BYP] = Minus 24 secs.
				[6] = Plus 24 secs.	[MEM] = Minus 28 secs.
				[7] = Plus 28 secs.	[TRBL] = Minus 32 secs.

Communicator Formats (* = supports 4-digit account codes only)					
Key		Key		Key	
[2ND]	= ADEMCO slow (1400Hz, 1900Hz, 10bps)	[6]	= RADIONICS with PARITY (1400Hz, 40bps)	[6]	= RADIONICS with PARITY (1400Hz, 40bps)
[1]	= (1400Hz, 1800Hz, 10bps)	[7]	= RADIONICS with PARITY (2300Hz, 40bps)	[7]	= RADIONICS with PARITY (2300Hz, 40bps)
[2]	= SILENT KNIGHT fast (1400Hz, 1900Hz, 20bps)	[8]	= * ADEMCO express	[8]	= * ADEMCO express
[3]	= SESCOA (2300Hz, 1800Hz, 20bps)	[9]	= * ADEMCO contact ID (programmable codes)	[9]	= * ADEMCO contact ID (programmable codes)
[4]	= RADIONICS (40bps with 1400Hz handshake)	[10]	= * ADEMCO contact ID (all codes)	[10]	= * ADEMCO contact ID (all codes)
[5]	= RADIONICS (40bps with 2300Hz handshake)	[TRBL]	= * PAGER FORMAT (personal dialing)	[TRBL]	= * PAGER FORMAT (personal dialing)

Programmable Contact ID Event Codes					
All addresses from 300 to 527 (sections 11 to 67) programmed with values other than [2ND] [2ND] will report the contact ID codes corresponding to the values programmed. Values to be programmed should be selected from this table.					
CID	Reporting Code	Prog. Value	CID	Reporting Code	Prog. Value
100:	AUXILIARY ALARM	[2ND] / [1]	300:	SYSTEM TROUBLE	[2] / [2]
110:	FIRE ALARM	[2ND] / [2]	301:	AC LOSS	[2] / [3]
111:	FIRE SMOKE	[2ND] / [3]	302:	LOW SYSTEM BATTERY	[2] / [4]
112:	COMBUSTION	[2ND] / [4]	305:	SYSTEM RESET	[2] / [5]
113:	WATER FLOW	[2ND] / [5]	306:	PROGRAM CHANGED	[2] / [6]
114:	HEAT	[2ND] / [6]	309:	BATTERY TEST FAIL	[2] / [7]
115:	PULLSTATION	[2ND] / [7]	320:	SOUNDER/RELAY TROUBLE	[2] / [8]
116:	DUCT	[2ND] / [8]	321:	BELL 1 TROUBLE	[2] / [9]
117:	FLAME	[2ND] / [9]	323:	ALARM RELAY TROUBLE	[2] / [10]
118:	NEAR ALARM	[2ND] / [10]	350:	COMMUNICATION TROUBLE	[2] / [11]
120:	PANIC ALARM	[2ND] / [11]	351:	TELCO 1 FAULT	[2] / [12]
121:	DURESS	[2ND] / [12]	354:	FAIL TO COMMUNICATE	[2] / [BYP]
122:	SILENT PANIC	[2ND] / [BYP]	370:	PROTECTION LOOP TROUBLE	[2] / [MEM]
123:	AUDIBLE PANIC	[2ND] / [MEM]	371:	PROTECTION LOOP OPEN	[2] / [TRBL]
130:	BURGLARY	[2ND] / [TRBL]	372:	PROTECTION LOOP SHORT	[3] / [2ND]
131:	PERIMETER BURGLARY	[1] / [2ND]	373:	FIRE LOOP TROUBLE	[3] / [1]
132:	INTERIOR BURGLARY	[1] / [1]	382:	SENSOR TROUBLE	[3] / [2]
133:	24HR BURGLARY	[1] / [2]	383:	SENSOR TAMPER	[3] / [3]
136:	BURGLARY OUTDOOR	[1] / [3]	400:	OPEN / CLOSE	[3] / [4]
137:	BURGLARY TAMPER	[1] / [4]	401:	OPEN / CLOSE BY USER #	[3] / [5]
138:	BURGLARY NEAR ALARM	[1] / [5]	402:	GROUP OPEN / CLOSE	[3] / [6]
140:	GENERAL ALARM	[1] / [6]	403:	AUTOMATIC OPENING / CLOSING	[3] / [7]
150:	24 HOUR AUXILIARY	[1] / [7]	404:	LATE TO OPEN / CLOSE	[3] / [8]
151:	GAS DETECTED	[1] / [8]	407:	REMOTE ARM DOWNLOAD	[3] / [9]
152:	REFRIGERATION	[1] / [9]	410:	REMOTE ACCESS	[3] / [10]
153:	LOSS OF HEAT	[1] / [10]	441:	OPEN / CLOSE - STAY MODE	[3] / [11]
154:	WATER LEAKAGE	[1] / [11]	570:	BYPASS	[3] / [12]
155:	FOIL BREAK ALARM	[1] / [12]	572:	24 HOUR ZONE BYPASS	[3] / [BYP]
156:	DAY TROUBLE ALARM	[1] / [BYP]	573:	BURGLARY BYPASS #	[3] / [MEM]
157:	LOW GAS LEVEL	[1] / [MEM]	574:	GROUP BYPASS	[3] / [TRBL]
158:	HIGH TEMPERATURE	[1] / [TRBL]	601:	MANUAL TEST	[4] / [2ND]
159:	LOW TEMPERATURE	[2] / [2ND]	602:	PERIODIC TEST	[4] / [1]
161:	LOSS AIR FLOW	[2] / [1]	625:	TIME / DATE RESET	[4] / [2]
			654:	SYSTEM INACTIVITY	[4] / [3]

REPORTING CODES

All digits from [1] to [F] are valid. [2ND] = digit will not be reported except for Contact ID programmable codes. For single digit reporting, enter "skip" ([2ND]) as the first digit (default = [2ND] / [2ND]).



Enter FF to program the default Ademco Contact ID report code when using the Ademco Contact ID (programmable codes) or Pager report formats.

If the Contact ID Format (all codes) is selected, addresses 300 to 527 (sections 11 to 67) do not have to be programmed. To select Contact ID (all codes) you must set key [10] at section 09/address 038 for both central station numbers (see page 4).

ARMING (CLOSING) REPORT CODES:

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
11	___/___	Auto / Espload	300	17	___/___	User Code 23	324
	___/___	Master	301		___/___	User Code 24	325
	___/___	User Code 1	302		___/___	User Code 25	326
	___/___	User Code 2	303		___/___	User Code 26	327
12	___/___	User Code 3	304	18	___/___	User Code 27	328
	___/___	User Code 4	305		___/___	User Code 28	329
	___/___	User Code 5	306		___/___	User Code 29	330
	___/___	User Code 6	307		___/___	User Code 30	331
13	___/___	User Code 7	308	19	___/___	User Code 31	332
	___/___	User Code 8	309		___/___	User Code 32	333
	___/___	User Code 9	310		___/___	User Code 33	334
	___/___	User Code 10	311		___/___	User Code 34	335
14	___/___	User Code 11	312	20	___/___	User Code 35	336
	___/___	User Code 12	313		___/___	User Code 36	337
	___/___	User Code 13	314		___/___	User Code 37	338
	___/___	User Code 14	315		___/___	User Code 38	339
15	___/___	User Code 15	316	21	___/___	User Code 39	340
	___/___	User Code 16	317		___/___	User Code 40	341
	___/___	User Code 17	318		___/___	User Code 41	342
	___/___	User Code 18	319		___/___	User Code 42	343
16	___/___	User Code 19	320	22	___/___	User Code 43	344
	___/___	User Code 20	321		___/___	User Code 44	345
	___/___	User Code 21	322		___/___	User Code 45	346
	___/___	User Code 22	323		___/___	User Code 46	347
				23	___/___	User Code 47	348
					___/___	User Code 48 / (Duress)	349
					---	Continues on next page.	

DISARMING (OPENING) REPORT CODES (reset code "empty")

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
23	___/___	Auto / Espload	350	30	___/___	User Code 25	376
	___/___	Master	351		___/___	User Code 26	377
24	___/___	User Code 1	352	___/___	User Code 27	378	
	___/___	User Code 2	353	___/___	User Code 28	379	
	___/___	User Code 3	354	31	___/___	User Code 29	380
	___/___	User Code 4	355		___/___	User Code 30	381
25	___/___	User Code 5	356		___/___	User Code 31	382
	___/___	User Code 6	357		___/___	User Code 32	383
	___/___	User Code 7	358	32	___/___	User Code 33	384
	___/___	User Code 8	359		___/___	User Code 34	385
26	___/___	User Code 9	360		___/___	User Code 35	386
	___/___	User Code 10	361		___/___	User Code 36	387
	___/___	User Code 11	362	33	___/___	User Code 37	388
	___/___	User Code 12	363		___/___	User Code 38	389
27	___/___	User Code 13	364		___/___	User Code 39	390
	___/___	User Code 14	365		___/___	User Code 40	391
	___/___	User Code 15	366	34	___/___	User Code 41	392
	___/___	User Code 16	367		___/___	User Code 42	393
28	___/___	User Code 17	368		___/___	User Code 43	394
	___/___	User Code 18	369		___/___	User Code 44	395
	___/___	User Code 19	370	35	___/___	User Code 45	396
	___/___	User Code 20	371		___/___	User Code 46	397
29	___/___	User Code 21	372		___/___	User Code 47	398
	___/___	User Code 22	373		___/___	User Code 48 / (Duress)	399
	___/___	User Code 23	374				
	___/___	User Code 24	375				

ALARM REPORT CODES FOR ZONES 1 TO 10:

Streamline Section	Data	Description	Address
36	___/___	Zone 1	400
	___/___	Zone 2	401
	___/___	Zone 3 (fire add. 100)	402
	___/___	Zone 4	403
37	___/___	Zone 5	404
	___/___	Zone 6	405
	___/___	Zone 7	406
	___/___	Zone 8	407
38	___/___	Zone 9	408
	___/___	Zone 10	409
	[2ND] / [2ND]	Future Use	410
	[2ND] / [2ND]	Future Use	411
39 to 41		Future Use	412-423

ALARM RESTORE REPORT CODES FOR ZONES 1 TO 10

Streamline Section	Data	Description	Address
42	___/___	Zone 1	424
	___/___	Zone 2	425
	___/___	Zone 3 (fire add. 100)	426
	___/___	Zone 4	427
43	___/___	Zone 5	428
	___/___	Zone 6	429
	___/___	Zone 7	430
	___/___	Zone 8	431
44	___/___	Zone 9	432
	___/___	Zone 10	433
	[2ND] / [2ND]	Future Use	434
	[2ND] / [2ND]	Future Use	435
45 to 47		Future Use	436-447

ZONES 1 TO 10 SHUTDOWN REPORT CODES:

Streamline Section	Data	Description	Address
48	___/___	Zone 1	448
	___/___	Zone 2	449
	___/___	Zone 3 (fire add. 100)	450
	___/___	Zone 4	451
49	___/___	Zone 5	452
	___/___	Zone 6	453
	___/___	Zone 7	454
	___/___	Zone 8	455
50	___/___	Zone 9	456
	___/___	Zone 10	457
	[2ND] / [2ND]	Future Use	458
	[2ND] / [2ND]	Future Use	459
51 to 53		Future Use	460-471

TAMPERS 1 TO 4, 5 AND 7 REPORT CODES

Streamline Section	Data	Description	Address
54	___/___	Tamper 1 (ATZ)	472
	___/___	Tamper 2	473
	___/___	Tamper 3 (ATZ)	474
	___/___	Tamper 4	475
55	___/___	Tamper 5 (ATZ)	476
	[2ND] / [2ND]	Future Use	477
	___/___	Tamper 7 (ATZ)	478
	[2ND] / [2ND]	Future Use	479
56 to 59		Future Use	480-495

TROUBLE REPORT CODES:

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
60	___/___	Max. aux. current	496	61	___/___	Fire loop trouble	500
	___/___	Bell disconnect / max. bell current	497		___/___	Timer loss	501
	___/___	Battery disconnect / low voltage	498		[2ND]/[2ND]	Future Use	502
	___/___	Power failure	499		[2ND]/[2ND]	Future Use	503

TROUBLE RESTORE REPORT CODES:

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
62	___/___	Max. aux. current	504	63	___/___	Fire loop trouble	508
	___/___	Bell disconnect / max. bell current	505		___/___	Timer programmed	509
	___/___	Battery disconnect / low voltage	506		___/___	Tamper / wiring fault	510
	___/___	Power failure	507		___/___	TLM restore	511

SPECIAL REPORT CODES:

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
64	___/___	Test report	512	66	___/___	Duress	520
	___/___	Panic 1	513		___/___	Closing Delinquency	521
	___/___	Panic 2	514		[2ND]/[2ND]	Future Use	522
	___/___	Panic 3	515		[2ND]/[2ND]	Future Use	523
65	___/___	Late to close	516	67	___/___	Login (Espload)	524
	___/___	No movement	517		___/___	Program Change	525
	___/___	Partial Arming	518		[2ND]/[2ND]	Future Use	526
	___/___	Recent Close	519		[2ND]/[2ND]	Future Use	527

DECIMAL PROGRAMMING


The decimal programming method is used to program all of the system's timers. This method uses a 3-digit address from **044** to **061** and each address is programmed with a value from **000** to **255**.

Table 5: Decimal Programming Method

- 1) Press **[ENTER]** + **[INSTALLER CODE]** (default: 282828)
- 2) The **[ENTER]** key will flash to indicate you are in programming mode
- 3) Enter 3-digit **[ADDRESS]** (**044** to **061**)
- 4) The keypad displays the current 3-digit data saved at this address as described in Figure 2 below
- 5) Enter 3-digit **[DATA]** (000 to 255) and do not press **[ENTER]**, the software will automatically save the data
- 6) Return to step 2 or press **[CLEAR]** to exit programming mode

Address	Data	Description	Default
044	___ / ___ / ___	(hours) Auto arm time (between "000" and "023")	
045	___ / ___ / ___	(minutes) Auto arm time (between "000" and "059")	
046	___ / ___ / ___	(days or hours) Auto test report every ? (between "001" and "255") (000 = disabled) If address 090 key [3] OFF = address 046 in days (see page 10) If address 090 key [3] ON = address 046 in hours (see page 10)	
047	___ / ___ / ___	(hours) Auto test report (between "000" and "023")	
048	___ / ___ / ___	(minutes) Auto test report (between "000" and "059")	
049	___ / ___ / ___	(seconds) Exit delay	60 seconds
050	___ / ___ / ___	(seconds) Entry delay 1	45 seconds
051	___ / ___ / ___	(seconds) Entry delay 2	45 seconds
052	___ / ___ / ___	(minutes) Bell cut-off time	5 minutes
053	___ / ___ / ___	(x 15 ms) Zone speed	600 ms
054	___ / ___ / ___	(minutes) Power failure report delay (000 = disabled)	30 minutes
055	___ / ___ / ___	(x 15 minutes) "No movement" report time (000 = disabled)	Disabled
056	___ / ___ / ___	PGM timer setting (001 to 127 for seconds and 129 to 255 for minutes) Add 128 to desired value in minutes (i.e. for 5 minutes: enter 5 + 128 = 133)	5 seconds
057	___ / ___ / ___	Intellizone delay (in seconds, minimum = 10 seconds)	48 seconds
058	___ / ___ / ___	Installer code lock (147 = locked, 000 = unlocked). When Installer Lock is enabled on a control panel: For 4 seconds during power up, the STATUS LED flashes while the dialer relay opens and closes making a clicking noise.	
059	___ / ___ / ___	(seconds) Programmable delay before alarm transmission (005 to 063 seconds) (000 = disabled)	
060	___ / ___ / ___	(seconds) Recent closing delay (000 = disabled)	
061	___ / ___ / ___	(days or hours) Closing delinquency timer (System A) If address 090 key [3] OFF = address 061 in days (see page 10) If address 090 key [3] ON = address 061 in hours (see page 10)	Disabled

Figure 2: Decimal Display For LED Keypads



FEATURE SELECT PROGRAMMING

Addresses **062** to **126** are programmed using the Feature Select Programming method. In this method, every key on the keypad in each address represents an option or feature. Pressing a key will display it on the keypad and pressing it again will extinguish the key. The ON or OFF status of each key determines the selected feature. Addresses **080** to **085** are reserved for future use. To program using the Feature Select Programming method:

Table 6: Feature Select Programming Method

- 1) Press **[ENTER]** + **[INSTALLER CODE]** (default: 282828)
- 2) The **[ENTER]** key will flash to indicate you are in programming mode
- 3) Enter 3-digit **[ADDRESS]** (**062** to **126**)
- 4) After entering the address, the keypad will display the feature selection status. Turn the keys ON or OFF by pressing the appropriate key until the desired options are set. Press the **[ENTER]** key to accept, there will be a confirmation "beep" indicating the options have been accepted. The **[ENTER]** key will flash to indicate that the software is awaiting the next address entry.
- 5) Return to step 3 to continue programming or press **[CLEAR]** to exit programming mode

Table 7: Code Priority For System "A" / STAY

	KEY SELECT:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]	[11]	[12]	[BYP]	[MEM]	[TRBL]	[2ND]
062	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
064	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
066:	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Table 8: Code Priority For System "B" / AWAY

	KEY SELECT:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]	[11]	[12]	[BYP]	[MEM]	[TRBL]	[2ND]
068:	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
070:	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
072:	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Table 9: Code Priority for Codes with Bypass Access

	KEY SELECT:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]	[11]	[12]	[BYP]	[MEM]	[TRBL]	[2ND]
074:	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
076:	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
078:	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

086:

See "TLM" table at right

Keyswitch = regular arm

Keyswitch arming

Call back

Auto arm on time

Auto arm on no movement

Pulse dialing

Partitioning

Silent zone/panic generates a silent alarm

(1:2) Pulse Europe

See "Reporting Options" table at right

N/A

Bell squawk on arm/disarm

Auto zone shutdown

	OFF	KEY /	ON	
	<input type="checkbox"/>	[2ND]	<input type="checkbox"/>	
	<input type="checkbox"/>	[1]	<input type="checkbox"/>	
	<input type="checkbox"/>	[2]	<input type="checkbox"/>	Stay arm / System A
	<input type="checkbox"/>	[3]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[4]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[5]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[6]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[7]	<input type="checkbox"/>	Tone dialing (DTMF)
	<input type="checkbox"/>	[8]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[9]	<input type="checkbox"/>	generates only a report
	<input type="checkbox"/>	[10]	<input type="checkbox"/>	(1:1.5) Pulse USA
	<input type="checkbox"/>	[11]	<input type="checkbox"/>	
	<input type="checkbox"/>	[12]	<input type="checkbox"/>	
	<input type="checkbox"/>	[BYP]	<input type="checkbox"/>	N/A
	<input type="checkbox"/>	[MEM]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[TRBL]	<input type="checkbox"/>	Enabled

Telephone Line Monitoring (TLM)		
KEY		
[2ND]	[1]	
OFF	OFF	- TLM disabled
OFF	ON	- TLM generates trouble only
ON	OFF	- generates an alarm if armed
ON	ON	- silent alarm becomes audible

(address 086, key [9] has to be OFF)

Reporting Options		
KEY		
[11]	[12]	
OFF	OFF	- Reporting disabled
OFF	ON	- Regular reporting
ON	OFF	- Split* reporting (Alarms & System)
ON	ON	- Double reporting

Report Dialing Sequence (tel. no.)
 Regular: 1,2,1,2,1,2,1,2, fail to comm.
 Split*: Alarms - 1,1,1,1,1,1,1,1, fail to comm
 System - 2,2,2,2,2,2,2,2, fail to comm
 Double: 1,1,1,1,1,1,1,1, fail to comm
 2,2,2,2,2,2,2,2, fail to comm

*** On alarm, all reports are made to Tel. #1 until system is disarmed. Once disarmed, system reports are made to Tel. #2.**

088:

Automatic event buffer transmission

Panic 1 (keys [1] and [3])

Panic 2 (keys [4] and [6])

Panic 3 (keys [7] and [9])

Panic 1 silent

Panic 2 silent

Panic 3 silent

Key [10] - regular arming

Key [11] - stay or system A arm

6-digit access codes

Tamper Recognition

Beep on exit delay

Report zone restore on bell cut-off

Zones with EOL (1kΩ)

Always report disarm

	OFF	KEY /	ON	
	<input type="checkbox"/>	[2ND]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[1]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[2]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[3]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[4]	<input type="checkbox"/>	Audible
	<input type="checkbox"/>	[5]	<input type="checkbox"/>	Audible
	<input type="checkbox"/>	[6]	<input type="checkbox"/>	Fire
	<input type="checkbox"/>	[7]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[8]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[9]	<input type="checkbox"/>	4-digit access codes
	<input type="checkbox"/>	[10]	<input type="checkbox"/>	
	<input type="checkbox"/>	[11]	<input type="checkbox"/>	
	<input type="checkbox"/>	[12]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[BYP]	<input type="checkbox"/>	On zone closure
	<input type="checkbox"/>	[MEM]	<input type="checkbox"/>	No EOL
	<input type="checkbox"/>	[TRBL]	<input type="checkbox"/>	Only after alarm

Tamper / Wire Fault Definitions			
	KEY		
	[10]	[11]	
System Armed	OFF	OFF	System Disarmed*
Alarm as per individual zone definitions	OFF	OFF	- Tamper supervision disabled
Always generate trouble and alarm, audible or silent as per individual zone definitions	OFF	ON	- No alarm, trouble code reported
	ON	OFF	- Silent alarm. Trouble & alarm codes reported
	ON	ON	- Audible alarm. Trouble & alarm codes reported**

*** Exception: for 24 hour zones, the tamper definition will follow the audible/silent alarm definition of the 24 hour zone.**
**** Silent zones will generate a silent alarm.**

090:

Exclude power failure from trouble display

Zone 4 enabled*

Auto arm = regular arm

Auto test report / Closing delinquency timer in days

Restrict arming on battery failure

Restrict arming on tamper trouble**

No tamper bypass

Zone doubling (ATZ) wiring in series

Zone doubling (ATZ)

Audible trouble warning

Duress

Keypad zone 1 supervision

Keypad zone 2 supervision

Master code lock

Pager format (wait delay)



Pager report alarms only


	OFF	KEY /	ON	
	<input type="checkbox"/>	[2ND]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[1]	<input type="checkbox"/>	Disabled*
	<input type="checkbox"/>	[2]	<input type="checkbox"/>	Stay / System A
	<input type="checkbox"/>	[3]	<input type="checkbox"/>	In hours
	<input type="checkbox"/>	[4]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[5]	<input type="checkbox"/>	Enabled**
	<input type="checkbox"/>	[6]	<input type="checkbox"/>	Tamper follows zone bypass definition
	<input type="checkbox"/>	[7]	<input type="checkbox"/>	Parallel
	<input type="checkbox"/>	[8]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[9]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[10]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[11]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[12]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[BYP]	<input type="checkbox"/>	Enabled
	<input type="checkbox"/>	[MEM]	<input type="checkbox"/>	Personal dialing (during delay)
	<input type="checkbox"/>	[TRBL]	<input type="checkbox"/>	All events

*** NOTE 1: When ATZ is enabled (address 090 key [8] ON) and zone 3 is defined as a fire zone, zone 4 must be disabled.**

**** NOTE 2: Only the installer can clear a tamper trouble**

Table 10: Zone Definition

Address	KEY SELECT:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]
092:	Zone: Intellizone = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
096:	Zone: Silent = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
100:	Zone: 24Hr./Fire = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3* <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
	Keypad zones cannot be set as 24Hr. zones.										
		*When zone 3 is defined "24Hr.", it becomes a fire zone									
104:	Zone: Instant = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
108:	Zone: Follow = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
112:	Zone: Delay 2 = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
		SYSTEM A / STAY (if ON, zone is armed on Stay or "System A" arming)									
116:	Zone:	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
		SYSTEM B (if ON, zone is armed in "System B" arming)									
120:	Zone:	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>
124:	Zone: Bypass = ON	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>	8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>

 **Do not use the Intellizone feature and an entry delay for the same zone, otherwise an alarm may occur as a user tries to disarm the system. Zones that are not selected at addresses 100 to 112 become "Delay 1" zones.**

KEY ACCESS PROGRAMMING

Programs features quickly, without entering addresses or sections numbers. To activate Key Access Programming, press [ENTER] followed by the installer code, master code or user code 1 (code required depends on the desired feature; see below). Press the key corresponding to the desired feature. Press [ENTER] or [CLEAR] to exit. When communicating with Esplod, it is impossible to enter programming mode.

Table 11: Key Access Programming

Key	Feature	Codes that can access feature
[8]	Installer Test Mode In Installer Test mode, a confirmation beep (intermittent) indicates that the test mode is enabled. A rejection beep indicates that the test mode is disabled. The bell will squawk during walk testing to indicate opened, functional zones.	<i>Installer Code Only</i>
[9]	"Auto Arming" Time Program Key [9] flashes. Enter 2-digit hour (00 to 23) and 2-digit minutes (00 to 59).	<i>Installer Code, Master Code or User Code 1</i>
[MEM]	Panel Time Programming [MEM] key flashes. Enter 2-digit hour (00 to 23) and 2-digit minutes (00 to 59).	<i>Installer Code, Master Code or User Code 1</i>
[BYP]	Test Report Reporting is enabled at address 086 , keys [11] and [12] (see page 10). A value must be entered at address 512 (page 7) and both telephone and account numbers must be programmed.	<i>Installer Code, Master Code or User Code 1</i>
[TRBL]	Call Esplod Via Telephone Panel identifier and PC password (addresses 004 to 007 on page 2) and computer telephone number (addresses 008 to 015 on page 3) must be programmed.	<i>Installer Code, Master Code or User Code 1</i>
[AWAY]	Answer Esplod This feature is available when using the ADP-1 adapter. In Esplod, "blind dial" must be activated in "modem setup" section and panel phone number programmed.	<i>Installer Code, Master Code or User Code 1</i>
[STAY]	Cancel Communication Attempts Until next reportable event.	<i>Master Code/User Code 1 only cancel calls to Esplod The Installer Code can cancel all communications</i>

CONNECTION DIAGRAMS

The system hardware will recognize the following zone conditions:

SINGLE ZONE CONNECTIONS

Figure 3: N.C. Contacts, without EOL Resistor




Figure 4: N.C. Contacts, with EOL Resistor (UL/ULC)




Figure 5: N.O. Contacts, with EOL Resistor (UL/ULC)




Figure 6: N.C. Contacts, without EOL Resistor, with Tamper Recognition





Figure 7: N.C. Contacts, with EOL resistor, with Tamper and Wire Fault Recognition (UL/ULC)



ADVANCED TECHNOLOGY ZONE CONNECTIONS

Figure 8: N.C. Contacts, without EOL Resistor




Figure 9: N.C. Contacts, without EOL Resistor, with Tamper Recognition




Figure 10: N.O. Contacts, with EOL Resistor, with Tamper and Wire Fault Recognition (UL/ULC)





Figure 11: Parallel Wiring



OTHER CONNECTION DIAGRAMS

Figure 12: Connecting One Keypad Zone




Figure 13: Connecting Two Keypad Zones Using Two Keypads




Figure 14: Keypad Tamper Switch Connection




Figure 15: PGM Output Relay




Figure 16: Ground Start Circuit




Figure 17: Fire Alarm Zone Connections





Figure 18: Fire Reset



Note: It is recommended that the smoke detectors be connected using a daisy chain configuration.

WIRING DIAGRAM

STATUS LED:

Flash once every sec. = normal
 Toggle ON 1 sec./ OFF 1 sec. = trouble
 Always ON = panel is using phone line
 Fast flash 4 secs. after power up = installer lock enabled

For use with the 708, Esprint and SRI-18 PGM expander

Note: To use you must disable the PGM. To do so, program [2ND] [2ND] in sections 039, 040 and 042.

Caution: Disconnect the battery before replacing the fuse

WARNING: Disconnect the telephone line before servicing.

Rechargeable Acid/Lead or Gel Cell Backup Battery: UL/ULC - 12Vdc, 4Ah/7Ah

UL: K12 model T16 V40
 ULC: Frost model FTC 1637

WARNING: Improper connection may result in damage to the system.

AUX POWER:
 450mA maximum. 250mA maximum for 24Hr Stand-by.
 To connect additional wiring to the auxiliary power, use the red (+) and the black (-) keypad connectors. AUX power will shutdown if current exceeds 650mA.

Note: For UL installations, the metallic enclosure must be grounded to the cold water pipe or to the grounding rod.


To provide maximum lightning protection we strongly recommend having separate earth connections for the dialer and zone ground terminals.

Keypads - LED Keypads 636 and 646 - LCD Keypad 642


The maximum number of keypads per installation is dependent on the auxiliary output, which is not to exceed 450mA. Refer to the *Reference & Installation Manual* for the current consumption table. Refer to Figure 12 and Figure 13 on pages 13 and 14 for information on keypad zone connections.

All outputs are Class 2 or power-limited, except for the battery terminal. The Class 2 or power-limited fire alarm circuits shall be installed using CL3, CL3R, CL3P or substitute cable permitted by the National Electrical Code, ANSI/NFPA 70.

Inset 1: Zone Recognition for the 728 Ultra with ATZ Enabled



Inset 2: Connecting the Bell/Siren



POWER DOWN RESET

Performing a power down reset will set the installer and master codes to factory default. Values entered at addresses 008 to 043, 062 to 124, 300 to 527 and all user codes will be set to factory defaults. Programmed values at addresses 004 to 007 do not change. To perform a reset, the installer lock must be disabled. To perform a power down reset perform the following:

- 1) Verify installer lock is disabled
- 2) Remove the battery and AC power from the control panel.
- 3) Short the **PGM** and zone **1** terminals with a wire.
- 4) Reconnect the AC and battery power to the control panel.
- 5) Wait 10 seconds and remove the wire.

Figure 19: Power Down Reset

